

ASSEMBLY GUIDE

Magnetic Mount Assembly

Hue Remote Holder, attaching magnets to your print

This guide walks you through attaching the mounting magnets to your printed Hue Remote Holder. Your Hue remote already has its own magnets built in, so we use those to set the correct polarity automatically, so nothing gets glued in backwards.

WHAT YOU'LL NEED

- **2 neodymium disc magnets**, 10mm x 2mm
- Your **Philips Hue remote** (has built-in magnets)
- Your **printed Hue Remote Holder Plate**
- **Adhesive**, B-7000 recommended (most strong multi-purpose glues work)

ASSEMBLY STEPS

1**Lay out your materials**

Gather your printed holder, your Hue remote, the two magnets, and your glue.

**2****Set the magnets' orientation on the remote**

Place the two magnets face-down onto the back of the Hue remote, aligned with the print's magnet holes, the remote's built-in magnets will pull them into the correct orientation. Then add a small amount of glue into the two magnet holes on the print.



3

Transfer the magnets into the print

Line the remote up next to the print. Moving one magnet at a time, slide it off the remote and press it straight into the glued hole without flipping it, then repeat for the second magnet.



4

Confirm both magnets are seated

Both magnets should now be glued into place in the print, as shown.



5

Test the orientation

Before the glue sets, hold the remote up to the front of the holder to confirm it snaps on securely. If it holds firmly, you're done, let it be, if not, gently remove and reseal the magnet before the glue cures.



CURE TIME Let it cure for **24 hours** before attaching your holder to the wall plate. This gives the adhesive time to fully set so your magnets stay put.

]]>